

DNA
DIAGNOSTIC

User Manual Pneumo 4V

RNA extraction – cDNA synthesis - qPCR - Interpretation



USER MANUAL
Cat No. PN4V96
DNA Diagnostic A/S
www.dna-diagnostic.com
Revision 2018.10.23

TABLE OF CONTENTS

| | |
|---|---|
| 1. PURPOSE OF THE TEST | 3 |
| 2. PRINCIPLE OF THE TEST | 4 |
| 3. KIT COMPONENTS AND STORAGE..... | 5 |
| 4. REQUIRED EQUIPMENT AND MATERIALS NOT INCLUDED IN THE KITS..... | 6 |
| 5. PROTOCOL..... | 7 |

Trademarks:

Black Hole Quencher® (BHQ®) and CAL Fluor® dye technologies incorporated in this product are used under licensing agreement with Biosearch Technologies, Inc. and protected by U.S. and world-wide patents issued, or in application.

1. PURPOSE OF THE TEST

Calf pneumonia is a major problem in dairy and beef herds worldwide because it can result in serious economic loss due to the direct costs of calf losses and treatment. Calf pneumonia can be viral or bacterial in origin, but most often an initial viral infection is followed by a bacterial infection.

Pneumo 4V is a fast, reliable and easy-to-use method for the detection of the primary viral pathogens (Bovine parainfluenza virus, Bovine coronavirus, Bovine Respiratory Syncytial virus, Bovine viral diarrhea virus and Bovine Herpesvirus 1) linked to calf pneumonia. Using a simple 96 deepwell-based extraction protocol followed by a sensitive and highly specific RT-qPCR reaction, the entire protocol from RNA extraction to result can be carried out in 5 hours.

2. PRINCIPLE OF THE TEST

Pneumo4V allows the detection of Bovine parainfluenza virus, Bovine coronavirus, Bovine Respiratory Syncytial virus, Bovine viral diarrhea virus and Bovine Herpesvirus 1 in tracheal aspirate fluid sample from calves. It includes the following four main steps:

The RNA extraction step uses the Pneumo 4 Extraction Kit for RNA extraction from 0.5 mL of sample. The sample is incubated with pre-lysis buffer at 37 °C for 10 minutes and then spun and washed. The RNA is extracted by incubating sample in the lysis mix buffers at 37 °C for 20 minutes followed by 95°C for 15 minutes and debris is pelleted by centrifugation. Now the RNA is in the supernatant.

The cDNA synthesis step uses 5 µL of RNA template which is added to a well in a 96 well plate containing ready to use Pneumo4V cDNA master mix. The cDNA synthesis reaction runs for 1 hour and 15 minutes.

The PCR step uses 2 µL of cDNA template which is added per well in a 96 well qPCR plate containing Pneumo4 qPCR master mix. The qPCR reaction run for approximately 52 minutes. Each qPCR reaction contains four sets of primers and fluorescence probes for specific detection of five viruses. A fifth set of primers and probe detects an internal amplification control (IAC). Each of the four probes emit a specific light (color) enabling the identification of viruses present in the sample. Probes with CY5, ROX, HEX and FAM fluorophores are present for detection of Bovine parainfluenza virus, Bovine coronavirus, Bovine Respiratory Syncytial virus and Bovine viral diarrhea virus/Bovine Herpesvirus 1 amplicons, respectively. The tests use the standard 96 well plate format and ready-to-use reaction mixes. The test requires only pipettes, a vacuum aspirator, a centrifuge, incubation oven, a thermal heating block and a qPCR instrument.

The interpretation step involves inspection of the amplification plots. The functionality of the qPCR reaction is controlled by the presence of IAC amplicons resulting in an ATTO signal with a Ct value at 27-32. The CY5, ROX, HEX and FAM signals ≤ 37 show the sample is positive for Bovine parainfluenza virus, Bovine coronavirus, Bovine Respiratory Syncytial virus and Bovine viral diarrhea virus/Bovine Herpesvirus 1 amplicons, respectively. No Ct value shows that the sample is negative.

3. KIT COMPONENTS AND STORAGE

The Pneumo4V kit contains material for testing 96 samples.


The Pneumo4V kit contains one box for storage at room temperature (RT) and **one box** for storage at -20°C:

| BOX | COMPONENTS | AMOUNT | STORAGE |
|-----|---|---|---------|
| I | Sealed 96 Deep Well Plates containing pre-lysis solution | 1 x 96 Deep Well Plate | RT |
| | Wash Buffer | 1 bottle of 110 mL | RT |
| | 96 Well Plates (0.2 mL clear tubes) with cap | 1 x 96 well plate (0.2 mL clear tubes) with cap | RT |
| | Adhesive seals for Deep Well plates | 4 pieces | RT |
| | Cap mats for the qPCR 96 Well Plates | 1x 96 cap for qPCR tube | RT |
| II | Lysis Buffer-I | 1 bottle of 12 mL | -20°C |
| | Mix I Additive for Lysis Buffer-I | 1 tube of 1334 µl | -20°C |
| | Sealed 96 Well Plates (0.2 mL clear tubes) with Pneumo 4V cDNA Master Mix | 1 x 96 well plates | -20°C |
| | Sealed 96 Well Plates (0.2 mL white tubes) with Pneumo 4V qPCR Master Mix | 1 x 96 well plates | -20°C |

4. REQUIRED EQUIPMENT AND MATERIALS NOT INCLUDED IN THE KITS

- Centrifuge for 96 well plates. Centrifuge **must be capable of running at 5000 x g at 37°C.**
Example: Heraeus Multifuge X3R Centrifuge with HIGHPlate 6000 rotor.
- Incubator at 37°C.
- Plate washer / vacuum system capable of aspirating supernatant from Deepwell plates.
Recommended: Bio-Rad DW40 plate washer.
Alternative: Vacuum system with pipette tips (35mm from tip to rim stop).
- qPCR instrument, Stratagene Mx3005 with filters for ATTO (440nm-492nm), FAM (492nm-516nm), HEX (535nm-555nm), ROX (585nm-610nm), CY5 (635nm-665nm).
- Vortexer for 96 well plates.
- Ice bucket or 0-4°C cooling block.
- Standard lab pipettes and sterile filter tips.

5. PROTOCOL



RNA extraction:

1. Centrifuge a 96 Deep Well Plate containing 150 µl of pre-lysis buffer at 1000 xg for 1 minute and remove seal.
2. Transfer 0.5 mL of samples to the corresponding well of the 96 well plate with pre-lysis buffer.
3. Pipette briefly up and down to mix the sample and cover wells with seal.
4. Incubate at 37°C for 10 minutes.
5. Spin Deep Well plate at 5000 xg for 5 minutes at 37°C.
6. Remove supernatant with the plate washer. Be careful not to touch or remove the pellets.
Note: It is important to remove all supernatant from the pellet. Therefore, correct adjustment of the plate washer syringes is required.
7. Add 1 mL Wash Buffer to Deep Well plate.
8. Cover wells with seal and vortex briefly.
9. Centrifuge the plate at 5000 xg for 5 minutes.
10. Remove supernatant with the plate washer. It is important to remove the supernatant completely. Be careful not to touch or remove the pellets.
11. Prepare fresh Lysis-I Mix by adding 6 µL Mix I additive to 54 µL Lysis buffer-I.

| Lysis-I Mixer | 1 reaction | 9 reaction | 50 reaction | 100 reactions |
|----------------|------------|------------|-------------|---------------|
| Lysis Buffer-I | 54 µL | 486 µL | 2700 µL | 5400 µL |
| Mix I additive | 6 µL | 54 µL | 300 µL | 600 µL |
| Total | 60 µL | 540 µL | 3000 µL | 6000 µL |

12. Add 60 µL Lysis-I Mix, to each pellet. Vortex and spin 20 seconds at 1000 xg to bring Lysis mixer to the bottoms.
13. Transfer of 60 µL from each sample into the corresponding tubes in the 96 well plate (clear 0.2 mL) and close the tubes with the caps. Avoid cross contamination.
14. Incubate the 96 well plate at 37°C for 20 minutes and at 95°C for 15 minutes.
15. Cool the 96 well plate on ice for 5 minutes
Note: The incubation at 37°C and 95°C can be done using a PCR instrument programmed:

37°C for 20 min. → 95°C for 15 min. → 4°C for 5 minutes.

16. Centrifuge the plate at 5000 xg for 5 minutes.

If lysate sample subsequently will be used for bacteria detection, follow the step 17 on Pneumo 4B manual protocol.

17. Carefully transfer 5 µL of each aqueous phase directly to the corresponding well of the 96 well plate with cDNA Master Mix in step 20.

Note: Due to the instability of RNA, it is recommended to perform the cDNA synthesis before storing samples.

cDNA Synthesis:

18. Take a Pneumo 4V cDNA master mix plate from freezer and thaw it on ice. Briefly spin the plate to collect the cDNA master mix in the bottom.

19. Remove and discard the seal from cDNA master mix plate.

20. Carefully transfer 5 µL supernatant from the 96 well 0.2 mL plate (step 17) to the corresponding well in the Pneumo 4V cDNA master mix plate (clear 0.2 mL).

21. Incubate the cDNA reaction at 37°C for 60 minutes.

22. Inactivate Reverse Transcriptase enzyme by heating to 70°C for 15 minutes.

23. Cool the cDNA reaction tube on ice for 1 minute and spin it again for 1 minute to collect condensate.

Note: The cDNA samples can be kept at -20°C until use.

qPCR analysis:

24. Take a Pneumo 4V qPCR master mix plate (white 0.2 mL) from freezer and thaw it on ice. Briefly spin the qPCR plate to collect the qPCR master mix in the bottoms.

25. Remove and discard the seal from qPCR plate.

26. Carefully transfer 2 µL supernatant from the 96 well 0.2 mL plate (step 23) to the corresponding well in the Pneumo 4V qPCR master mix plate.

Note: It is important to keep Master Mix on ice while loading template and to run the qPCR within 15 minutes.

27. Carefully cover the qPCR reaction plate with new lids and spin at 1000-1500 xg for 30 seconds to 1 minute.

28. Insert qPCR plate into the qPCR instrument.

29. Run the qPCR reaction using the instrument setting and the running program below:

Instrument settings for the MX3005P qPCR machine

Filter Gain Settings:

| ATTO | CY5 | ROX | HEX | FAM |
|------|-----|-----|-----|-----|
| 1x | 1x | 1x | 1x | 2x |

Note: If the raw data signal (R) is lower than 5000 for a color at the cycles 7-11 then increase the filter gain setting during the next runs resulting in a raw data signal (R) of 5000.

The guidelines for setting baseline and threshold should be checked manually to ensure that threshold lines are in the exponential area of the amplification plot and above the background.

Threshold Fluorescence: Select “Background Based Threshold” to cycles 7-11 and set the “Sigma multiplier” to 10.

To avoid bias of threshold wells including amplification curve with Ct<15 is flagged out. The threshold is then looked based on the rest of the sample and the sample with Ct<15 are put into the analysis again.

Baseline Correction: Select “Adaptive baseline”.


Activate the following filters: ATTO, CY5, ROX, HEX, FAM.

qPCR running program

| Condition | Temperature | Duration | Number of cycles | Stage |
|---------------------|-------------|----------|------------------|----------------|
| Heat activation | 95°C | 1 min | 1 | Pre-incubation |
| Denaturation | 95°C | 5 sec | 40 | Amplification |
| Annealing/extension | 60°C | 25 sec* | | |

* Read fluorescence for ATTO, FAM, HEX, ROX, CY5 at the end of each annealing/extension step.

Interpretation of analysis:



Amplification plot with the number of PCR cycles is shown on the x-axis, and the background subtracted fluorescence from the amplification reaction is shown on the y-axis. The threshold line is used to find the Ct value, where it intersects the amplification curve. Ct is optimally determined in the early exponential phase, when the fluorescence starts increasing due to PCR amplification. The threshold line is calculated automatically by the instrument giving in this example a Ct value of 14.

30. Check amplification plot for ATTO signals and the signals should be present in all reactions. The Ct must be in the interval 27-32 to confirm the qPCR reaction is functional.

*Note: ATTO Ct can be above 32 or missing if the Ct for one or more of FAM, HEX, ROX, CY5 is low. Then the DNA sample should be diluted 5-10 times and a new qPCR reaction should be analyzed using this diluted DNA. A dilution of 10 times will theoretically move Ct values 3.3 higher. Reactions with no FAM, HEX, ROX, CY5 signal and ATTO signal absent or outside the interval 27-32 **must be retested**.*

31. Check amplification plot for CY5, ROX, HEX, FAM signals and interpret the results as described in the table below.

| Target | Filter | Positive Ct | Negative Ct | Retest Ct |
|--|--------|----------------|----------------|---------------|
| Bovine parainfluenza virus | CY5 | ≤37 | >37 or absent | |
| Bovine coronavirus | ROX | ≤37 | >37 or absent | |
| Bovine Respiratory Syncytial virus | HEX | ≤37 | >37 or absent | |
| Bovine viral diarrhea virus and Bovine Herpesvirus 1 | FAM | ≤37 | >37 or absent | |
| IAC | ATTO | ≤32 | | >32 or absent |

Note: Sample with Ct values below 37 are considered as true positive.

Sample with Ct values above 37 should be considered negative.

For more information, contact

DNA Diagnostic A/S
Voldbjergvej 14
8240 Risskov
Denmark
Tel.: +45 8732 3050
E-mail: info@dna-diagnostic.com
www.dna-diagnostic.com

DNA Diagnostic A/S was established in 1992. DNA Diagnostic A/S is an ISO 13485 certified developer, manufacturer, and worldwide supplier of PCR based in vitro diagnostic kits.

Cat. No.:PN4V96

USER MANUAL

■ ----- www.dna-diagnostic.com ----- ►